

*NOTE: ON-SITE SHOT ROCK MAY BE USED FOR 2' BASE LAYER.
VOID SPACE MUST BE FILLED WITH 1" MINUS OR OTHER ADEQUATE
MATERIAL TO CREATE A SMOOTH BASE SUITABLE FOR NON-WOVEN
GEOTEXTILE FABRIC AND WASTE MATERIAL PLACEMENT.

