

Notes:

- This figure is focused on sulfolane detections. Sulfolane was not detected in private well or monitoring well samples collected outside the area shown.
- If a well has insufficient data points to assess a trend (less than 4 samples) and the analyte was not detected, the well is symbolized with "All Results Non-Detect".
- Overlapping trends are offset from exact well locations for reporting purposes; the deepest well in the cluster is centered on the cluster location.
- Image provided courtesy of Pictometry International 2012

### 2015 Third Quarter Offsite Sulfolane Trends Monitoring Wells and Private Wells

#### Private Wells

- All Results Non-Detect
- Stable
- Probably Decreasing
- ▼ Decreasing
- Probably Increasing
- ▲ Increasing
- No Trend
- Insufficient Data Points
- Point of Entry (POE) System
- Approximate Sulfolane Isopleth Regardless of Depth

#### Monitoring Wells

- All Results Non-Detect
- Stable
- Probably Decreasing
- ▼ Decreasing
- Probably Increasing
- ▲ Increasing
- No Trend
- Insufficient Data Points
- FHRA Property Boundary
- ND Non-Detect




Figure 1A