



ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE02-10-01 EX	Naukati Bay Surku Cove a. Lat. 55° 50.642'N Lon. 133° 9.509'W Slow Creek b. Lat. 55° 51.690'N Lon. 133° 9.473'W Gulchi Creek c. Lat. 55° 52.842'N Lon. 133° 8.161'W Naukati Creek d. Lat. 55° 53.246'N Lon. 133° 8.821'W Yatuk Creek e. Lat. 55° 53.377'N Lon. 133° 9.399'W Kaikli Cove Creek f. Lat. 55° 53.025'N Lon. 133°11.729'W	Exclude oil from entering the identified streams and inlets.	Deploy anchors and boom with skiffs (class 6). Place protected-water boom in a chevron pattern in front of the entrance to designated creeks/rivers. Tend throughout the tide. Boom Lengths: a. 600 ft. b. 100 ft. c. 200 ft. d. 200 ft. e. 600 ft. f. 100 ft.	Deployment Equipment 1800 ft. protected-water boom 9 ea. anchor systems 24 ea. anchor stakes Vessels 2 ea. class 6 1 ea. class 3 Personnel/Shift 7 ea. vessel crew Tending Vessels 1 ea. class 6 1 ea. class 3 Personnel/Shift 3 ea. vessel crew	Vessel Platform	Naukati is road accessible from Craig/Klawock Via marine waters Chart 17403_1	Fish: chum, coho, pink, sockeye, dolly varden, cutthroat, steelhead Habitat: gravel beaches, sheltered tidal flats, rocky shores Human Uses: commercial fishing, high recreational area	Vessel master should have local knowledge. Bears are present in the area. Bear guard required. Consult with Incident Command to ensure ADFG- Title 16 and ADNR-Title 41 permits have been obtained. Consult the Site Selection Matrix for cultural resources designation. Consult the ADEC "Spill Tactics for Alaska Responders" manual for additional information on the deployment of these tactics. Site surveyed: not surveyed Tested: not yet
SE02-10-02	Naukati Bay a. Lat. 55° 50.642'N Lon. 133° 9.509'W b. Lat. 55° 52.842'N Lon. 133° 8.161'W	Passive Recovery Deploy passive recovery across the tidal flats in Naukti Bay.	Place sorbent material at locations most likely to be oiled prior to impacts. Depending on spill size, oil type and possible impacts, place and anchor an appropriate amount of snare line or sorbent boom to protect the tidal flats. Replace as necessary to maximize the recovery.	Deployment Equipment 2000 ft. snare line or sorbent boom (Estimated) 5 ea. anchor systems 8 ea. anchor stakes Vessels/Personnel/Shift Same as SE02-10-01 Tending Vessels/Personnel/Shift Same as SE02-10-01	Vessel Platform	Site accessible via road system. Via marine waters Chart 17403_1	Same as SE02-10-01	Vessel master should have local knowledge.
SE02-10-03	Naukati Bay Nearshore waters in the general area of: Lat. 55° 51.030'N Lon. 133°11.768'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Naukati Bay depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Naukati Bay area. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Naukati Dock	Via marine waters Chart 17403_1	Same as SE02-10-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.