

An example of the *Free-oil Recovery Tactic*. Actual deployment should be adjusted for local conditions.

Map Legend


Free-oil Recovery

Aerial photography of this area is unavailable at this time, but may be included as it becomes available.


**Geographic Response Strategies for Southeast Alaska Subarea, Zone 6**

# Johns Hopkins Inlet, SE06-13

Center of map at 58° 52.83' N Lat., 136° 58.36' W Lon.



This is not intended for navigational use.

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE06-13-01 	<b>John Hopkins Inlet</b> Nearshore waters in the general area of:  Lat. 58° 54.51'N Lon. 136°55.79'W	<b>Free-oil Recovery</b> Maximize free-oil recovery in the offshore & nearshore environment of John Hopkins Inlet depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of John Hopkins Inlet.  Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Bartlett Cove-53nm- via marine access	Via marine waters  Chart 17318_3	Marine Mammals: seal pupping area  Human Use: Wildlife viewing, high recreational use	Vessel master should have local knowledge.  Consult the ADEC “Spill Tactics for Alaska Responders” manual for additional information on the deployment of these tactics.  Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.  Glacial ice conditions may impede operations.  Site surveyed: not surveyed  Tested: not yet