



Arrowhead-N Taan Fjord, SE09-08

Center of map at 60° 04.94' N Lat., 141° 17.03' W Lon.

Geographic Response Strategies for Southeast Alaska Subarea, Zone 9



An example of the *Free-oil Recovery Tactic*. Actual deployment should be adjusted for local conditions.




An example of the *Deflection Booming Tactic*. Actual deployment should be adjusted for local conditions.



Map Legend

- Free-oil Recovery
- Deflection Booming
- Protected-water Boom
- Bears in Area, Guards Recommended

Aerial photography of this area is unavailable at this time, but may be included as it becomes available.



This is not intended for navigational use.

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE09-08-01 	Arrowhead-N and Taan Fjord a. Lat. 60° 04.47 N Lon. 141°16.29 W b. Lat. 60° 05.26 N Lon. 141°18.33 W	Deflection Deflect oil coming towards Arrowhead-N and Taan Fjord into the channel for free-oil recovery.	Deploy boom and anchor system with skiffs (class 6). At each locations, position in a cascaded fashion 3 x 300 ft. of protected-water boom at a proper angle to deflect oil from into the main channel for free-oil recovery. Tend throughout the tide.	Deployment Equipment 1800 ft. protected-water boom 18 ea. anchor systems Vessels 1 ea. class 3 1 ea. class 6 Personnel/Shift 5 ea. vessel crew Tending Vessels 1 ea. class 6 Personnel/Shift 2 ea. vessel crew	Vessel Platform	Via marine waters Chart 16741	Birds: waterfowl concentrations Marine Mammals - harbor seals Habitat- gravel beach	Vessel master should have local knowledge. Site surveyed: not surveyed. Tested: not yet
SE09-08-02 	Arrowhead-N and Taan Fjord Nearshore waters in the general area of: Lat. 60° 05.18'N Lon. 141°17.43'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Arrowhead-N and Taan Fjord depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Arrowhead-N and Taan Fjord. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Yakutat- 60nm	Via marine waters Chart 16741	Same as SE09-08-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.