


Portage Cove SRS, SE08-05

Center of map at 59° 14.01' N Lat., 135° 25.49' W Lon.

Geographic Response Strategies for Southeast Alaska Subarea, Zone 8



This is not intended for navigational use.





DV01b viewed from the east.



DV01a viewed from the east.

Map Legend

- Free-oil Recovery
- Diversion Booming
- Shoreside Recovery
- Protected-water Boom

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE08-05-01 	Portage Cove a. Lat. 59° 13.27'N Lon. 135°24.29'W b. Lat. 59° 14.40'N Lon. 135°25.33'W	Divert and Collect Divert oil to shore-side collection points determined by spill source and trajectory. If oil is moving along the coastline deployment may be effective.	Deploy anchors and boom with skiffs (class 6). Exact collection site should be determined by spill trajectory. At each location cascade 3 x 200 ft. section protected-water boom at proper angle to divert incoming oil to the collection site. Set-up collection site using shore-side collection units or if oil volume is minimal, use sorbent boom or snare line to provide collection of oil. Tend throughout the tide.	Deployment Equipment 1200 ft. protected-water boom 12 ea. anchor systems 4 ea. anchor stakes 2 ea. shore-side collection units Vessels 3 ea. class 6 Personnel/Shift 6 ea. vessel crew 3 ea. response techs Tending Vessels 1 ea. class 6 Personnel/Shift 3 ea. vessel crew 3 ea. response tech	Haines	Via marine waters Chart 17317	Fish- coho, cutthroat, dolly varden Habitat- exposed rocky shores, sandy beach Human Use – high recreational use, commercial fishing	Vessel master should have local knowledge. Consult the Site Selection Matrix for cultural resources designation. Consult the ADEC “Spill Tactics for Alaska Responders” manual for additional information on the deployment of these tactics. Site: not surveyed Tested: not yet
SE08-05-02 	Portage Cove Nearshore waters in the general area of: Lat. 59° 14.12'N Lon. 135°25.55'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Portage Cove depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Portage Cove. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Haines	Via marine waters Chart 17317	Same as SE08-05-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the SE AK Sub-Area Contingency Plan: http://www.dec.state.ak.us/spar/perp/plans/scp_se.htm.