

May 2014

DRAFT This tactic map is a working draft being used to develop a Geographic Response Strategy at this location. The tactics represented here have not been approved by the Subarea Committee and should not be considered final. If you have questions or comments please contact us by email at contact@nukaresearch.com.

Southeast Alaska Geographic Response Strategies

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE05-25-01	Sitkoh Bay a. Lat. 57° 29.17'N Lon. 134°53.45'W b. Lat. 57° 29.46'N Lon. 134°54.01'W	Exclusion Exclude oil from entering the Sitkoh Bay.	Deploy anchors and boom with skiffs (class 6). Approach at high tide. Place protected-water boom in a chevron pattern in front of the entrance to designated creeks/rivers. Tend throughout the tide. <u>Boom Lengths:</u> a. 300 ft. b. 2000 ft.	Deployment Equipment 2300 ft. protected-water boom 12 ea. anchor systems 8 ea. anchor stakes Vessels 1 ea. class 3 2 ea. class 6 Personnel/Shift 7 ea. vessel crew Tending Vessels 1 ea. class 3 1 ea. class 3 1 ea. class 6 Personnel/Shift 3 ea. vessel crew	Vessel Platform	Via marine waters Chart 17338_1	Fish: chum, sockeye, dolly varden, coho, pink, cutthroat, steelhead Habitat: sheltered rocky shore, gravel beach, marsh Human Uses: high recreational use, subsistence, commercial fishing	 Vessel master should have local knowledge. Bears are present in the area. Bear guard required. Consult with Incident Command to ensure ADFG-Title 16 and ADNR-Title 41 permits have been obtained. Consult the Site Selection Matrix for cultural resources designation. Consult the ADEC "Spill Tactics for Alaska Responders" manual for additional information on the deployment of these tactics. Survey: not yet Tested: not yet
SE05-25-02	Sitkoh Bay Nearshore waters in the general area of: Lat. 57° 28.58'N Lon. 134°52.04'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Sitkoh Bay depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Sitkoh Bay areas. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Angoon 12nm via marine waters	Via marine waters Chart 17338_1	Same as SE05-25-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.

Site Information for Southeast Alaska, SE05-25

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the SE AK Sub-Area Contingency Plan: http://www.dec.state.ak.us/spar/perp/plans/scp_se.htm.