



An example of the *Exclusion Booming Tactic*. Actual deployment should be adjusted for local conditions.



An example of the *Free-oil Recovery Tactic*. Actual deployment should be adjusted for local conditions.




Aerial photography of this area is unavailable at this time, but may be included as it becomes available.

# Geographic Response Strategies for Western Alaska Subarea, Island Zone

## Nash Harbor, WAK-106

Center of map at 60° 13.06' N Lat., 166° 52.90' W Lon.



This is not intended for navigational use.

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected (months)	Special Considerations
I-06-01 <div>EX</div>	<b>Nash Harbor</b>  a. Lat. 60° 12.29'N Lon. 166°56.34'W  b. Lat. 60° 12.19'N Lon. 166°51.10'W  c. Lat. 60° 13.38'N Lon. 166°48.45'W  d. Lat. 60° 14.20'N Lon. 166°47.70'W	<b>Exclusion</b>  Exclude oil from impacting the identified streams in Nash Harbor.	Deploy anchors and boom with skiffs (class 6) at high tide.  Place protected water boom in a chevron pattern in front of the entrances to the streams. Complete each array by placing 60 ft. of tidal seal boom on each leg.  Tend throughout the tide.  Boom Lengths: <div>a. 250 ft b. 200 ft c. 400 ft d. 200 ft</div>	<b>Deployment Equipment</b> 1050 ft. protected-water boom 480 ft. tidal seal boom 5 ea. anchor systems 16 anchor stakes <b>Vessels</b> 1 ea. class 3 2 ea. class 6 <b>Personnel/Shift</b> 7 ea. vessel crew/general techs <b>Tending Vessels</b> 1 ea. class 3 1 ea. class 6 <b>Personnel/Shift</b> 3 ea. vessel crew/general techs	Vessel Platform	Via marine waters  Chart 16006	Fish- intertidal spawning-salmon (June-Sept.)dolly varden, arctic char  Birds-waterfowl, seabird and shorebird nesting  Habitat- exposed rocky shore, marsh, peat shoreline, Exposed wavecut platform, sheltered tidal flats  Human use-subsistence	Vessel master should have local knowledge.  Title 41 permitting required from ADNRL  Surveyed: not yet  Tested: not yet
I-06-02 <div>FO-S</div>	<b>Nash Harbor</b> Nearshore waters in the general area of:  Lat. 60° 13.06'N Lon. 166°52.90'W	<b>Free-oil Recovery</b>  Maximize free-oil recovery in the offshore & nearshore environment of Nash Harbor depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of the Nash Harbor.  Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Mekoryuk	Via marine waters  Chart 16006	Same as I-06-01	Vessel master should have local knowledge.  Use extreme caution, shallow waters with numerous submerged hazards.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the Western Alaska Subarea Contingency Plan: [http://dec.alaska.gov/spar/perp/plans/scp\\_wak.htm](http://dec.alaska.gov/spar/perp/plans/scp_wak.htm).