


Hamilton Bay, SE04-10

Center of map at 56° 53.42' N Lat., 133° 50.22' W Lon.



Geographic Response Strategies for Southeast Alaska Subarea, Zone 4

This is not intended for navigational use.



EX01a viewed from the east.



EX01c viewed from the west.

Map
Legend

-  Free-oil Recovery
-  Exclusion Booming
-  Passive Recovery
-  Protected-water Boom
-  Snare or Sorbent Boom
-  Bears in Area, Guards Recommended

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected	Special Considerations
SE04-10-01 	Hamilton Bay a. Lat. 56° 53.34'N Lon. 133°44.32'W b. Lat. 56° 52.43'N Lon. 133°45.42'W c. Lat. 56° 52.47'N Lon. 133°47.58'W	Exclusion Exclude oil from entering the Hamilton Bay.	Deploy anchors and boom with skiffs (class 6). Place the specified amount of protected-water boom in a chevron pattern in front of the entrance to the streams and intertidal areas. Tend throughout the tide. <u>Boom Lengths:</u> a. 1500 ft. b. 400 ft. c. 400 ft.	Deployment Equipment 2300 ft. protected-water boom 12 ea. anchor systems 12 ea. anchor stakes Vessels 1 ea. class 3 2 ea. class 6 Personnel/Shift 7 ea. vessel crew Tending Vessels 1 ea. class 6 1 ea. class 3 Personnel/Shift 3 ea. vessel crew	Vessel Platform	Via marine waters Chart 17368_1	Fish: chum, dolly varden, coho, pink, cutthroat, steelhead Habitat: sheltered tidal flat, gravel beach, marsh Human Uses: high recreational use, subsistence, commercial fishing	Vessel master should have local knowledge. Bears are present in the area. Bear Guard required. Survey: not yet Tested: not yet
SE04-10-02 	Hamilton Bay Lat. 56° 53.55'N Lon. 133°44.86'W	Passive Recovery Deploy passive recovery across the tidal flats in Hamilton Bay.	Place sorbent material at locations most likely to be oiled prior to impacts. Depending on spill size, oil type and possible impacts, place and anchor an appropriate amount of snare line or sorbent boom to protect the tidal flats. Replace as necessary to maximize the recovery.	Deployment Equipment 1500 ft. snare line or sorbent boom (Estimated) 5 ea. anchor systems 8 ea. anchor stakes Vessels/Personnel/Shift Same as SE04-10-01 Tending Vessels/Personnel/Shift Same as SE04-10-01	Vessel Platform	Site accessible via road system. Via marine waters Chart 17368_1	Same as SE04-10-01	Vessel master should have local knowledge.
SE04-10-03 	Hamilton Bay Nearshore waters in the general area of: Lat. 56° 53.18'N Lon. 133°48.16'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Hamilton Bay depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of Hamilton Bay areas. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Kake- 9nm via marine waters	Via marine waters Chart 17368_1	Same as SE04-10-01	Vessel master should have local knowledge. Use extreme caution, shoal waters with numerous reefs and rocks, shallow mud flats and channels.