


An example of the *Exclusion Booming Tactic*. Actual deployment should be adjusted for local conditions.



An example of the *Free-oil Recovery Tactic*. Actual deployment should be adjusted for local conditions.

Map Legend


	Free-oil Recovery		Fast-water Boom
	Exclusion Booming		Tidal-seal Boom

Aerial photography of this area is unavailable at this time, but may be included as it becomes available.

Geographic Response Strategies for Western Alaska Subarea, Island Zone

Nariksiut/Ahding River, WAK-I05

Center of map at 60° 18.55' N Lat., 166° 45.77' W Lon.



This is not intended for navigational use.

ID	Location and Description	Response Strategy	Implementation	Response Resources	Staging Area	Site Access	Resources Protected (months)	Special Considerations
I-05-01 	Nariksmiut/Ahding River a. Lat. 60° 18.13'N Lon. 166°42.79'W b. Lat. 60° 16.62'N Lon. 166°46.02'W	Exclusion Exclude oil from impacting the identified Nariksmiut & Ahding Rivers.	Deploy anchors and boom with skiffs (class 6) at high tide. For (a) cascade 2 sections of fast-water boom across the channel at an angle to exclude the entrance. For (b) place boom in a chevron pattern in front of the entrance to the river. Complete each array by placing 60 ft. of tidal seal boom on each leg. Tend throughout the tide. Boom Lengths: a. 750 ft b. 550 ft	Deployment Equipment 1300 ft. fast-water boom 240 ft. tidal seal boom 8 ea. anchor systems Vessels 1 ea. class 3 2 ea. class 6 Personnel/Shift 7 ea. vessel crew/general techs Tending Vessels 1 ea. class 3 1 ea. class 6 Personnel/Shift 3 ea. vessel crew/general techs	Mekoryuk	Via marine waters Chart 16006	Fish- intertidal spawning-salmon (June-Sept.) Marine mammals-seals, walrus Birds-waterfowl, seabird and shorebird nesting Habitat- exposed rocky shore, marsh, peat shoreline, sheltered tidal flats Human use-subsistence	Vessel master should have local knowledge. Title 41 permitting required from ADNR. Surveyed: not yet Tested: not yet
I-05-02 	Nariksmiut/Ahding River Nearshore waters in the general area of: Lat. 60° 18.55'N Lon. 166°45.77'W	Free-oil Recovery Maximize free-oil recovery in the offshore & nearshore environment of Nariksmiut/Ahding River depending on spill location and trajectory.	Deploy free-oil recovery strike teams upwind and up current of the Nariksmiut/Ahding River. Use aerial surveillance to locate incoming slicks.	Deploy multiple free-oil recovery strike teams as required to maximize interception of oil before it impacts sensitive areas.	Mekoryuk	Via marine waters Chart 16006	Same as I-05-01	Vessel master should have local knowledge. Use extreme caution, shallow waters with numerous submerged hazards.

NOTE: Sensitive resource information can be found on other maps which can be accessed through the sensitive area section of the Western Alaska Subarea Contingency Plan: http://dec.alaska.gov/spar/perp/plans/scp_wak.htm.